



## Cedar Post Wrap Installation Instructions

1. Cut post wrap to correct length – Cut bottom side, Top is Labeled
  - a. Replace screws if any are cut off near the end of the post, Use #6 Pre-drill to drill new holes
2. Remove panel on 1 side just prior to install- Use T-15 driver to remove all #7 x 2 ¼” trim screws
3. Remove temporary blocks from inside wrap
4. Be sure to block existing post – Top, Bottom, and Center for wrap to fit properly
5. Slide wrap around existing post block out – Make sure removable side is to the inside of the porch
6. Use Titebond III glue (Included) when re-attaching removable side panel –
  - a. Make sure top of wrap & top of panel line up to insure pre-drilled holes are also in line
  - b. Clamps may be necessary to line up correctly and to insure joint is flush and tight
  - c. Wipe off Excess Glue
7. Attach wrap to blocking on interior structure using the 2 ¼” stainless steel trim screws provided
8. If applicable, install base wrap and/or capitol wrap using the 4 – 2 ¼” stainless steel trim screws provided
9. If applicable install Braces
  - a. Pre-drill for ½” galvanized lags - **NOTE: IF YOU DO NOT PRE-DRILL YOU COULD SPLIT THE WRAP**
  - b. Use Walnut plugs to cover bolt locations

114 Southgate Drive • Oxford, NC 27565  
Phone: (919) 693-8995 • Fax: (919) 693-2397

[www.southernwoodcraft.net](http://www.southernwoodcraft.net)