



Tapered Plug Installation Instructions

- 1.** Evaluate each tapered plug and pick the one that matches the grain pattern and color best for your application. Do not discard extra plugs; one plug in package will be used as a driver.
- 2.** The marked sided of the plug will go into hole first.
- 3.** Apply glue provided thoroughly to the inside of hole.
- 4.** Be careful to align grain and tap plug into hole using the extra plug as a driver.
- 5.** Drive plug in until flush with surface. Do not drive to far.
- 6.** Wipe off any excess glue with a damp rag.
- 7.** Sand or touch up with stain if necessary.

114 Southgate Drive • Oxford, NC 27565
Phone: (919) 693-8995 • Fax: (919) 693-2397

www.southernwoodcraft.net